

# **G70**

#### Cellular 2G or LTE-M / NB-IoT

Rugged and robust vehicle, trailer, or heavy equipment tracking device with inputs/outputs, remote immobilization for fleet management, equipment monitoring, driver ID, theft recovery, and more



#### **Real-Time Tracking**

High-precision GNSS wired tracking device



#### Inputs/Outputs

1 x Ignition Digital Input, 3 x Digital Inputs, 1 x Analog Input, 1 x Switched Ground Digital Output



#### **Backup Battery**

Internal Backup Battery in case of loss of power or tampering



#### **Driver ID**

Configure iButton®, TTL, or Wiegand inputs for Driver ID Readers



#### **Driver Behavior**

Run hour monitoring, accident and rollover detection, speeding, harsh braking and cornering, and more



#### **Remote Immobilization**

Immobilization option to safely disable vehicles and equipment remotely



#### **Ultra-Rugged**

Weatherproof and ultra-rugged IP67 Housing

# **Connectivity & Location**

## **2G Version**

| Module               | Quectel MC60 850/900/1800/1900 MHz   |
|----------------------|--|
| Constellation        | Concurrent GPS / GLONASS / Galileo   |
| Channels             | 99 Channel High Sensitivity Receiver   |
| Tracking Sensitivity | -167dBM industry-leading tracking performance  |
| SIM Size & Access    | Internal Micro 3FF SIM   |
| GNSS Assistance      | GNSS almanac and ephemeris data for greater sensitivity and position accuracy  |
| Low Noise Amplifier  | GPS signals are filtered and boosted by a SAW filter and low-noise amplifier (LNA) allowing operation where other units fail |

# LTE-M / NB-IoT Version

| Cellular Module      | Nordic nRF9160 Modem operates on all major global LTE-M and NB-IoT bands.  |
|----------------------|--|
|                      | Supported LTE bands:<br>LTE-M (Cat-M1): B1, B2, B3, B4, B5, B8, B12, B13, B14, B17, B18, B19, B20, B25, B26, B28, B66<br>NB-IoT (Cat-NB1/NB2): B1, B2, B3, B4, B5, B8, B12, B13, B17, B19, B20, B25, B26, B28, B66 |
| GNSS Module          | uBlox EVA-M8Q  |
| Constellation        | Concurrent GPS / GLONASS / Galileo   |
| Channels             | 72 Channel High Sensitivity Receiver   |
| Tracking Sensitivity | -167dBM industry-leading tracking performance  |
| SIM Size & Access    | Internal Micro 3FF SIM   |
| GNSS Assistance      | GNSS almanac and ephemeris data for greater sensitivity and position accuracy  |
| Low Noise Amplifier  | GPS signals are filtered and boosted by a SAW filter and low-noise amplifier (LNA) allowing operation where other units fail   |
| Cell Tower Location  | Cell tower location fallback for positioning when GPS can't get a fix  |

## **2G and LTE-M / NB-IoT Versions**

The following technical specs are shared across both versions of the G70 unless otherwise stated

#### **Power**

| Input Voltage                               | 8-36V DC (max)  |
|---|---|
| High-Performance Automotive<br>Power Supply | Stringent power "load dump" tests are conducted to ensure operation in the harshest automotive electrical systems. Built-in self-resetting fuse makes installation simple and safe. |
| Operating Current                           | 2G  |
|   | ≈250mA when moving  |
|   | + ≈60mA while internal battery charging   |
|   | LTE-M / NB-IoT  |
|   | ≈50mA when moving   |
|   | + ≈60mA while internal battery charging   |
| Intelligent Power Management                | Device enters sleep mode when vehicle is inactive to prevent battery drain  |
| Sleep Current                               | <1mA  |
| Backup Battery                              | 1100mAh LiPo internal backup battery pack   |

## **Mechanics / Design**

| Dimensions               | 125 x 80 x 25 mm (4.92 x 3.15 x 0.98")   |
|--------------------------|--|
| Weight                   | 170g   |
| Housing                  | Ultra-Rugged IP67 Housing. Non-branded housing for optional white-labeling.  |
| IP Rating                | IP67 rated housing ensures device can withstand fine dust, high-pressure spray, submersion for 30 mins in 1m of water, and extreme temperatures  |
| Installation             | 10 wire harness<br>1m Length   |
| Operating Temperature    | -30°C to +60°C (connected to external power)  At < 0°C and > +40°C the internal backup battery will not be charged as a safety precaution due to the dangers associated with charging batteries at extreme temperatures. |
| Cellular Antenna         | Internal   |
| GPS Antenna              | Internal   |
| 3-Axis Accelerometer     | 3-Axis Accelerometer to detect movement, high G-force events, and more   |
| Diagnostic LED           | Diagnostic LED indicates operation status  |
| Flash Memory             | Store weeks of records if device is out of cellular coverage. Storage capacity for over 10 days of continuous 30-second logging.   |
| On-Board Speed & Heading | The device continuously monitors speed and heading, allowing for over-speed alerts as well as updates on speed and heading changes   |
| On-Board Temperature     | The device reports internal temperature and prevents the internal battery charging in extreme temperatures. Internal temperature provides an indication of ambient temperature but may not always be precise.            |

### Interfaces

| Analog Inputs       | 1 x Analog input. 0-40V   |  |
|---------------------|---|--|
| Digital Inputs      | 3* x Digital Inputs with configurable pull up/pull down 0-48V DC input range  |  |
|                     | On/Off thresholds: Pull-up enabled: low at 0.4V, high at 1.9V Pull-down enabled: low at 0.8V, high at 2.2V  |  |
|                     | Can be used for pulse counting *Digital Input 3 pin shared with Driver ID. Cannot be used in conjunction with Wiegand or TTL readers.                 |  |
| Digital Outputs     | 1 x Switched Ground digital output - 2A max<br>Easily wired up to switch external lights, relays, buzzers, etc<br>Can be used to immobilize a vehicle |  |
| Ignition            | 1 x dedicated ignition digital input 0-48V DC - 2.2V on/off threshold<br>Can be used as a digital input if not required                               |  |
| TTL Interface       | Serial interface used to connect a Digital Matter RFID reader for Driver ID (requires external 5V power source)                                       |  |
| Wiegand             | Enables easy integration with a variety of Driver ID card types and readers or keypads  |  |
| 1-Wire® or iButton® | 1-Wire® or iButton® can be used to read Driver ID tags. Readers available to suit multiple card form  |  |

### **Smarts**

| Auto-APN                      | Auto-APN allows the device to analyze the SIM card and select the correct APN details from a list that is pre-loaded in the device's firmware.   |
|-------------------------------|--|
| Accident & Rollover Detection | Configure accident and rollover alerts triggered by extreme changes in velocity and orientation of vehicle or equipment. Second-by-second GPS data is saved on the device's flash memory, with a capacity of approximately 2 hours of data. In the event of an accident, a subset of the data (60 seconds before / 10 seconds after) is uploaded to the server automatically (if configured) or can be requested manually for a detailed reconstruction of the incident. |
| Driver ID Options             | RFID reader, iButton®, or Wiegand interface for Driver ID, access control, and logbooking  |
| Driver Safety & Behavior      | Monitor speeding, harsh acceleration, braking, cornering, idling, and more to improve safety and prevent unnecessary wear on vehicles  |
| Geofence Alerts               | The server can use device location to create geofences and alerts if an asset enters or leaves designated locations  |
| Geofence Download to Device   | Geofences can be downloaded directly to the device from Telematics Guru for enhanced location-based actions and alerts.  2G - Maximum of 20 Geofences with up to 30 points per geofence  LTE-M/NB-IoT - Maximum of 500 Geofences with up to 100 points per geofence  |
| GPS Jamming Detection         | GPS Jamming or Interference can be detected and alerted on   |
| In-Vehicle Alerts             | Can be wired up to external buzzers or lights for in-vehicle alerts  |
| Lone Worker Safety            | Interface a variety of duress pendants to enable man-down alerts for lone worker safety monitoring   |
| Preventative Maintenance      | Set reminders based on distance traveled and run hours to reduce maintenance and repair costs  |
| Real-Time Tracking            | Device remains continuously connected while on the move for real-time asset tracking   |
| Remote Immobilization         | Digital outputs can be connected to a relay to enable remote immobilization of vehicles and equipment in the case of theft, abuse, or unauthorized usage   |

## **Smarts (continued)**

| Run Hour Monitoring | Calculate run hours and distance traveled (odometer) to understand and optimize asset utilization   |
|---------------------|---|
| Sensor Monitoring   | Interface with a range of devices and switches for seatbelt detection, duress and panic buttons, lights, in-cab warning buzzers, and more |
| Tamper Alerts       | Instant alert if the device is disconnected from its power source   |
| Theft Recovery      | Switch to Recovery Mode in the case of theft or loss to activate real-time tracking for asset retrieval                                   |

## **Device Management**

| Flexible Configuration     | Configure device parameters such as position update rate, movement and accelerometer settings, and more to fit any tracking application |
|----------------------------|---|
| Device Management Platform | Manage, monitor, configure, debug, update, and restart devices remotely from our cloud-based device management system                   |
| Configuration App          | Configurable with DMLink provisioning tool  |

## Integration

|--|

# **Security**

| Data Security | Military-level AES-256 Encryption from device to Device Management Platform to protect the integrity and confidentiality of telematics data. Data forwarded to third-party systems is sent via HTTPS for end-to-end security. |
|---------------|---|
|               | to-end security.  |

## Warranty

| anty Two-year manufacturer's warranty |
|---------------------------------------|
| vo-year manufacturer's warranty       |

## **Certifications**

Please visit support.digitalmatter.com for a full list of compliance specifications and documentation for your region